

Intermittent Fault Box (Model 2112)



Features:

The Intermittent Fault Box provides a means of faulting circuits in vehicles.

- Faulted circuits are connected through standard banana jacks. The following faults can be inserted:
 - » Open
 - » Incorrect Resistance
 - » Short to Ground
 - » Short to Voltage
- Fault duration switch.
- Time between fault switch.
- Hard and intermittent switch.


12290 Chandler Drive
Walton, Ky 41094


Sales@atechtraining.com
ATechTraining.com


1-888-738-9924

